StatiCAD-Yigma

USER MANUAL

V.3.0.0.0

TABLE OF CONTENTS

Chapter 1 Introduction

1.1 StatiCAD-Yigma Software Description	
1.2 General Technical Features of the Software	5
Chapter 2 Installing the Software on PC	7
2.1 Installing the Main Software	7
2.2 Installing Supporting Programs	7
2.2.1 Pdf Creator Software	7
2.2.2 Adobe Reader Software	8
2.2.3 Vector Draw Lite File Converter Software	8
2.3 Running the Software	8
2.3 Updating the Software	8

Chapter 3 Data Entry with Graphic Editor (Draw)

3.1 Select Mode	9
3.2 Draw Axis	9
3.3 Draw Wall	13
3.4 Draw Slab	16
3.5 Draw Horizontal Bond Beam	21
3.6 Draw Vertical Bond Beam	22
3.7 Draw Door	24
3.8 Draw Window	26

3.9 Draw Foundation	29
3.10 Draw Retrofit Jacket	30
Chapter 4 File Menu	
New	_32
Open	32
Save	32
Save As	32
Rescue Last Project	32
Exit	32
Chapter 5 Edit Menu	33
Undo	33
Redo	33
Copy Story	33
Erase	34
Selection Mode	34
Make All Objects Unselected In the Story	34
Make All Objects Selected In the Story	34

Invert Selection in the Story_____34

Filter Selection _____35

Find Object ______35

Chapter 6 View Menu	36
Chapter 7 Modify Menu	
Selected Element Properties	36
Chapter 8 Analysis	
Load Transfers in a Story	38
Load Transfers between Stories	40
Performance and Retrofit	41
Determining The Earthquake Performance Of Existing Building	41
Drawing Retrofit Jackets	43
Retrofitted Building Analysis Options	46

This page was intentionally left blank.

Chapter 1 Introduction

1.1 StatiCAD-Yigma Software Description

StatiCAD-Yigma is computer software that functions in static analysis and project drawings of masonry constructions as per earthquake code.

The software can perform static calculations and drawings of masonry constructions in accordance with earthquake code 2007.

The software at once resolves the building system constructed with axis, wall, slab, horizontal bond beam, vertical bond beam, door basic elements drawn in the graphic interface; regarding analysis options. Performed analysis include earthquake code 2007 geometry checks, shear and mass center checks, shear and vertical stress checks on walls, slab calculations, and preparing report files.

All project drawings including project cover can be collected at once with a single button. Drawings can be edited by the integrated drawing editor, or can be exported to graphic design software like AutoCAD.

1.2 General Technical Features of the Software

- 1.2.1 A complete modeling of the building by basic elements: axis, wall, slab, horizontal bond beam, vertical bond beam, door, window
- 1.2.2 Ease of editing and use by commands like undo, redo, find object, zoom in, zoom out, layer, calculate distance, auto-name elements, merge walls, select all, select none, invert selection, delete object, copy object, change object properties
- 1.2.3 Customized pop-up menu based on the right-clicked element
- 1.2.4 Zoom function by scrolling center mouse wheel, pan function by clicking center mouse wheel and dragging
- 1.2.5 Selective reporting based on analysis results (horizontal bond beam loads, wall loads, slab calculations, earthquake loads on stories, shear and mass center summary table,

shear center coordinates, wall shear forces, wall vertical stress checks, wall shear stress checks)

- 1.2.6 Creating evaluation report for the building by terms from the earthquake code regarding masonry buildings
- 1.2.7 Saving reports and drawings in PDF format
- 1.2.8 Automatically drawing section details for project drawings
- 1.2.9 Selective story copying
- 1.2.10 While drawing, following operations can be performed optionally: Automatic setting of sheet size, automatic adding project cover, foundation application plan and foundation bond beam detailed drawings, drawing wall plan, displaying door and window locations in wall plan, adding horizontal and vertical bond beam detailed drawings to wall plan or formwork plan, drawing formwork sections and slab reinforcements.
- 1.2.11 Drawings can be edited in internal drawing editor or exported as dxf/dwg file format without shape loss.
- 1.2.12 Integrated multi-functional drawing editor for organizing, modifying and printing project drawings
- 1.2.13 Fault checks after analysis: Displaying construction elements with insufficient sections and walls with insufficient lengths
- 1.2.14 Retrofitting calculations and reports
- 1.2.15 Retrofitting section drawings

Chapter 2 Installing the Software on PC

2.1 Installing the Main Software

2.1.1 Run the StatiCAD-Yigma_Setup_v3.xxx.exe setup file provided in the installation CD.

2.1.2 Click "İleri" (Next) in the displayed form. If you agree with the terms, click " Lisans sözleşmesini tüm maddeleri ile kabul ediyorum" (I accept all articles of the license agreement) option, and then click "İleri" (Next).

Do not change the installation directory "C:\Program Files\StatiCAD Yigma". Click "Başlat" (Start) for starting the installation.

When the software is automatically installed and "StatiCAD-Yigma Başarı ile kuruldu" (StatiCAD-Yigma has been installed successfully) message is displayed, the installation is completed.

2.1.3 Exit installation by clicking "İleri" (Next) and "Çıkış" (Exit) buttons.

2.2 Installing Supporting Programs

StatiCAD-Yigma comes with a bundle of supporting programs for full functionality. You can find the supporting programs in the installation CD, in supporting programs folder. Supporting programs and their functions are listed below. Supporting programs are not provided with the demo version. They can be downloaded from our website <u>http://www.staticad-yigma.com</u>.

2.2.1 Pdf Creator Software: This program enables you to save report and drawing files created by StatiCAD-Yigma in PDF format. It also allows any printable document to be converted into PDF format. For personal uses, you can convert any document to PDF by selecting PDF creator as a printer in your print menu and clicking "Print" button. This is a freeware program.

To install PDF Creator, run the PDFCreator-x_x_x_setup.exe program located in C:\Program Files\StatiCAD Yigma\ supporting programs. Do not change the printer name during installation.

If the software is already installed in your computer, the installation may not be completed. In this case, you can remove the old program (Control Panel/Add or Remove Programs) and install the new version.

You can download the new version of the freeware PDF Creator program from our website <u>www.staticad-yigma.com</u> or <u>http://www.pdfforge.org/</u>.

2.2.2 Adobe Reader Software: Enables you to display the documents created by the software or other programs in PDF format. If the software is already installed, you can skip reinstalling it.

To install Adobe Reader, run the AdbeRdrxxx_tr_TR.exe program located in C:\Program Files\StatiCAD Yigma\ supporting programs.

You can download the latest version of the software from http://get.adobe.com/reader/

2.3 Running the Software: Attach the program dongle provided with the installation CD to your computer. Installation of the dongle will be performed automatically. When the dongle is attached for the first time, automatic installation generally takes less than 60 seconds. After the dongle is recognized by the computer, a success message is displayed. Now you can run StatiCAD-Yigma software.

We hope you enjoy your experience with this software...

2.4 Updating the Software: Run the StatiCAD-Yigma_3_xxx_Guncelleme_Setup.exe program. Click "İleri" (Next) in the displayed form. If you agree with the terms, click "Lisans sözleşmesini tüm maddeleri ile kabul ediyorum" (I accept all articles of the license agreement) option, and then click "İleri" (Next).

Do not change the installation directory "C:\Program Files\StatiCAD Yigma". Click "Başlat" (Start) for starting the installation.

When the software is automatically installed and "StatiCAD-Yigma Başarı ile kuruldu" (StatiCAD-Yigma has been installed successfully) message is displayed, update is completed.

Upgrade or downgrade can be performed by this process. By installing the update, you will upgrade your program to the current version, whether you have installed the previous versions or not.

Chapter 3 Data Entry with Graphic Editor (Draw)

3.1 Selection Mode

Only one construction object is active in project data entry in Draw menu. Project objects may first need to be selected, in order to modify them. Toggle selection mode to select objects and exit drawing mode.

To enter selection mode, you can either click the selection mode button in the Draw toolbar of the main window, or you can click Selection Mode option in Draw menu. When the object is in drawing mode (wall, slab, etc.) a right click will automatically cancel the active mode and enter selection mode.

To select objects, you can create a selection frame. Clicking on the objects will also select or deselect them.

To create a selection frame, first and second points of the frame is marked by left mouse click. Selected objects are displayed in orange color.

3.2- DRAWING AXIS

Axes should necessarily be drawn first, in order to perform any drawing in StatiCAD-Yigma software. Axes are drawing guides that ensure the project is carried out by sharp and absolute measures. As static calculations are based on axes; static connections between elements connected to different axes in walls, horizontal bond beams and slabs in the same story cannot be considered. However, sharing axes of same coordinates or names is not necessary for the objects to perform load

transfer between stories. Draw Axis toolbar can be displayed by clicking Axis button.



When Draw Axis button is clicked in the main window, draw axis toolbar is displayed. Buttons in this toolbar and their functions are listed below.



Draw axis according to the marked options

If no axis was previously drawn in the specified direction, first horizontal or vertical axis can be drawn by setting axis distance to 0 (or any other number) and clicking \bigotimes button when is selected.

To draw axis, orientation of the axis should be specified by clicking \bigcirc or \bigcirc button.

or the button should be selected in order to specify whether the axis will be drawn according to the distance from last axis or the distance from marked axis.

If \square button is on, reference axis should be selected with left mouse click, accordingly with the selection status of \square or \bigcirc buttons.

		Axis Distance 300	cm 1		1. 1 .	2
	Axis is drawn by entering the displacement range in		un	box and	clicking	
button.						

This procedure is repeated for every axis to be drawn.

To delete a drawn axis, select the axis by left clicking; and then right click over the axis or

another object and select Erase from the drop-down menu. You can also click the button in the main window, or select Erase option from Edit menu.

To move an axis, right click on the axis and select Axis Property Change. Move the axis by entering displacement range or global coordinates in the displayed window.

🐊 Axis Property Change in XX Direction 🛛 💶 🗙	Axis Property Change in YY Direction _ □ >
Axis ID XX1	Axis ID YY2
Enter Global Coordinate (Y=) 300 cm	Enter Global Coordinate (X=) 600 cm
Or	Or
Enter Displacement Range (Delta Y=) 0 cm	Enter Displacement Range (Delta X=) 0 cm
Y=300(New Global Coordinate)	X=600(New Global Coordinate)
Move objects on the axis when moving axis	Nove objects on the axis when moving axis
Ok Cancel	Ok Cancel
Oblique Axle Move Axle ID: XY1 Entering the displacement distance, or by changing the axle equation Oblique axle equation: A.x+B.y+C=0	you can move Oblique Axis
-300 *X+ -300 *Y+ 270	000 =0
Enter displacement distance of oblique ax 0 Down (+) Up Direction (-)	cm
Ok Cancel	

Figure: Dialog windows for moving horizontal, vertical and oblique axis

To draw an oblique axis, orthogonal drawing mode (ortho) option **b** should be disabled.

To draw an oblique axis, button is selected; first and second points of the oblique axis are marked in the main window, regarding the intersection points of previously drawn axes.

To erase an incorrect oblique axis, left click on an empty area on the axis, then click erase command in the right-click menu or Edit menu.

3.3- DRAWING WALL

To draw walls, wall properties form is displayed by clicking the **second** button in the main window.

Wall Properties			×	
General Settings S	tatic / Material	Analysis Option	s	
Wall ID	W101			
Wall Width	20	cm		
Beam Height	40	cm	Horizontal Bond Beam Height over the wall	
Wall top level	0	cm	Relative Distance between story up level and Horizontal Bond Beam Top Level over the wall (down -)	
Wall Bottom Level	0	cm		
Extra G	0	kg/m	Wall additional dead load	
Extra Q	0	kg/m	Wall additional live load	
Eccentricity	0	cm	Scroll distance of wall meridian from axis	
*Wall IDs generated automatically. **Horizontal Bond Beam width over the wall is automatically generated. Do not draw horizontal bond beams over the walls again ***Wall bottom level must be zero exept gradually buildings.				
OK Cancel <u>H</u> elp				

There are three tabs for data entry in the Wall Properties window.

3.3.1 General Settings Tab

There is no need to enter any information in the wall ID section. The software automatically assigns names to walls while drawing.

Wall widths are entered as centimeters.

Horizontal bond beam height over the wall is entered. Horizontal bond beam width over the wall is automatically generated as the width of the wall stated here. Horizontal bond beam over the wall is automatically drawn when the wall is drawn. No additional bond beam should be defined over the wall. If additional bond beams are defined over the wall; the slab load would be distributed both to the wall and horizontal bond beam, and the bond beam would transfer the load to the construction elements at endpoints; so load transfer would be performed twice. To avoid such error, no horizontal bond beam should be defined over the wall. Horizontal bond beams over the wall are automatically generated.

Wall Top Level value is the distance between story top coordinate point and horizontal bond beam top level over the wall. Wall Bottom Level is the distance of the wall base from the story base defined in general story settings. Wall Bottom Level value should be zero except for gradual buildings. Distance values are positive (+) for up, negative (-) for down. Story coordinate settings and descriptions are performed in general story settings. If you prefer to draw a wall of the same height as the story, Wall Top Level and Wall Bottom Level values should remain zero.

For example, for a wall with the wall top level 1m below the story top level, wall top level value should be set to -100. After the value is set, horizontal bond beam top level over the wall would be 100 cm below the story level.

Wall Prope	rties			×
General S	ettings	Static / Material	Analysis Option	ıs
-Wall Ma	terial Se	lection		
 E1 Ve E2 Ve E3 Ve E4 Fill E5 St E6 Ga E7 Fill 	rtical ha rtical ha rtical ha ed block one wall is concre ed conc	Illow block brick (hai Illow block brick (hai Illow block brick (hai k brick or clay brick (with lime mortar s ete (with adhesive) rete briquette (with	low rate is less low rate is in be low rate is more (with lime morta upported with c n cement mortar	than 35 %, with lime mortar supported with cement) tween 35 – 45 %, with lime mortar supported with cement) e than 45 %, with lime mortar supported with cement) r supported with cement) ement))
Secilen D	istom De	zemesinin		
Unit Weig	ht	1500	kg/m3	
fem		1	Мра	Pressure Safety Stress of Wall (Not Reduced According to Slenderness Ratio)
το		0.25	Мра	Cracking safety stress of wall
In retro	itting pr	ojects fem and to e	edit boxes must	have resistance of the existing material
			ОК	Cancel Help

3.3.2 Static/Material Tab

If one of the defined walls E1-E7 is selected; wall unit weight, pressure safety stress of wall and cracking safety stress of wall values are selected from earthquake code tables and entered in relevant boxes. If E1-E7 defined material is used, those values need not be changed and are colored green.

Table 5.3 of Earthquake Code 2007 is used for Pressure Safety Stress of Wall value (fem) that is automatically selected. If desired, user can perform modeling by entering values obtained from methods within the scope of Turkish Earthquake Code 2007, 5.3.2 Pressure Safety Stress on Walls or other methods and experiments.

In retrofitting projects, fem and to boxes shall be filled with current material strengths. Current material strengths are Pressure Safety Stress of Wall (not reduced according to slenderness ratio) and Cracking Safety Stress of Wall, obtained empirically in the existing building. Cracking safety stress of the wall is the shear resistance stress of the wall calculated empirically, without vertical loads.

For information about the necessity of performing pressure strength experiments, refer to articles related to Existing Building Reviews and Retrofits.

Unit weights of walls can be calculated by the user and can be entered to the software as kg/m^3 ; or the values given in the program can be used for E1-E7 materials.

3.3.3 Analysis Options

Nall Properties	x
General Settings Static / Material Analysis Options	
Wall Stiffness Multiplier	— II
In k*A/H expression k Stiffness Multiplier will be selected by program)	
In k*A/H expression k Stiffness Multiplier will be custom defined	
	$\leq \parallel$
In new design buildings k Stiffness Multiplier should be 1.0 or 1.2 In retrofitting projects you can custom define strengthened walls relative stiffness	
OK Cancel Help	

In retrofit projects, custom values can be defined for k stiffness factor, by reasons like considering composite section relative stiffness or using different relative wall stiffness.

If the option to select k multiplier by the program is clicked, k value will be set to 1,2 if there is a vertical bond beam or a perpendicular wall at wall end; otherwise, k value will be 1.0.

3.4- DRAWING SLAB

Important note: In order to perform load transfer, slab edge should be supported from the center of the element (static axis), to which load will be transferred.

In StatiCAD-Yigma software, slabs are used for transferring loads and self weights to walls. Slab calculation axes enable the reinforcement calculations of concrete slabs. Lack of slab calculation axis in an area where a slab is present would result in lack of concrete slab calculation and drawing operations. Similarly, lack of slab in an area where slab calculation axis is present would cause lack of load transfer from the calculation axis to wall; and slab calculation axis weights cannot be used in earthquake calculations. When slab is created with rectangular slab or quadrilateral slab commands, slab calculation axes are automatically generated with the same properties. In slabs with special shapes like L, T, Z, H; slab calculation axes' coordinates should be changed in order to draw slab reinforcements in a proper way. In such situations, slab calculation axes can be modified with commands like of the properties. As calculation axes are automatically generated except special

conditions, no other operation is necessary.

By definition, different G and Q loads, levels, slab heights and supporting conditions can be applied to slabs and slab calculation axes. So, when you change G, Q, K, Level values of drawn slabs, you should change slab calculation axis properties as well (if there are no special conditions).

To draw sl	ab, slab properties form is	displayed by clicking the	button in the main window.
When	button is selected, (s	slab toolbar is displayed)	slab drawing mode is active.
🔗 Slab 🛙	raw		
5 7	G 175 Q 200 H	12 Level 0	Slab RC Axis
	kg/m2 kg/m2	cm cm	Edit Draw Del. Setting

Total coating load except self concrete weight (ceiling coating+leveling concrete under coating+coating weight+etc..) is entered in the $\frac{G_{kg/m2}}{kg/m2}$ box in Draw Slab toolbar. Entry unit is kg/m^2 .

Live load on the slab and slab calculation axis is entered in the kg/m² box in Draw Slab toolbar.

Q 200

H 12

is the concrete height of slab and slab calculation axis. It can be changed if necessary.

Level 0

cm is the elevation of slab surface from the story up level defined in general story settings. Positive (+) values refer to up, negative (-) values refer to down. For example, Level value should be set as -25 for a slab 25 cm below the story ceiling.

Software is in rectangular slab drawing mode when substantiation is selected in the Draw Slab toolbar. When top left and bottom right points of the slab are selected by left mouse click, the software draws the rectangular slab and slab calculation axes.

Software is in quadrilateral slab drawing mode when \bigvee button is selected in the Draw Slab toolbar. Rectangular or quadrilateral slabs can be drawn. To define slab, four corners should be clicked in the main window, with respect to nodes. When top left, bottom right, bottom left, top right points of the slab are selected by left mouse click, the software draws the quadrilateral slab and slab calculation axes.

If clickings are performed in a different order, the software rearranges the clicking order.



When slab is drawn, load transfer areas are displayed (with bisectors drawn from slab corners) as if all slabs are supported from four sides. After the analysis, the software tries to display load transfer areas accurately for slabs supported from 1-2-3 sides.

If any slab bisector intersection points (blue inner lines) are present outside the slab, it will be convenient to erase the slab and redraw it. After the analysis, the software detects the slabs that perform faulty load transfer and highlight those on the main screen, reporting the slab is incorrect. In such cases, it would be convenient to erase the incorrect slab and rerun analysis.

Page **18**

While transferring loads from the slab to horizontal bond beams and walls, StatiCAD-Yigma linearizes load transfers compared to triangular and trapezoid areas and performs load transfer to connected elements. In order to perform load transfer, slab edge should be supported from the center of the element (static axis), to which load will be transferred.

If there are no bearing elements in the entirety of slab edge, there is not any problem with load transfer. However, slab concrete calculations can only be carried out in four-side and one-side supported slabs (cantilever). Efforts were taken in order to preserve safety for two and three side supported slabs.

If there are no bearing elements (wall, horizontal bond beam) in parts of slab edge, no load transfer is performed in those parts. As the calculations slightly differ for slabs of L, T, +, H, etc. shapes; a user willing to make more accurate calculations can place horizontal bond beams next to slab edges, in order to maintain continuity.

Slab static and concrete calculations are performed with regard to the simple method presented in TS.500. The user must investigate the situations that the method can be used; and must perform slab calculations as well where the method cannot be used.

When slab is created with rectangular slab sor quadrilateral slab commands, slab calculation axes are automatically generated with the same properties. In slabs with special shapes like L, T, Z, H; slab calculation axes' coordinates should be changed in order to draw slab reinforcements

in a proper way. In such situations, slab calculation axes can be modified with commands like \vec{r}_{ed} , \vec{r}_{ed} and \vec{r}_{ed} . As calculation axes are automatically generated except special conditions, no other operation is necessary.

When delete Del. command is active in Draw Slab toolbar, slab calculation axis can be deleted by clicking on it.

When edit Edit command is active in Draw Slab toolbar, after deleting slab calculation axis, a new axis with the same properties can be created by clicking top left, bottom right, bottom left and top right points of the slab calculation axis.

When Draw command is active in Draw Slab toolbar, a new axis can be created by clicking top left, bottom right, bottom left and top right points of the slab calculation axis. A new slab calculation axis is created.

Note: \square and \square commands create slabs and slab calculation axes at the same time, where \square command only creates slab calculation axis. It does not recreate the slab used in load transfer and earthquake calculations. Except for special conditions, \square and \square commands will suffice.

If a wall is defined over the slab, no load transfer is performed between up story walls and down story slabs. Hence, when it is necessary to define wall over the slab, it would be convenient to draw horizontal bond beam under the wall (down story ceiling) If no horizontal bond beam is present, beam height can be equal to slab height.



button opens a window, from which Draw Slab toolbar settings can be performed in another form. This feature is not necessary for new slabs and slab calculation axes to be drawn. When slab or slab calculation axis properties will be changed, property changes are done in this form.

🔗 Döşeme Özellikl	eri		
ID	<mark>501</mark>	Slab ID	
h	12	cm	Slab Thickness
G coating	175	kg/m2	Slab Coating weight per unit area
Q	200	kg/m2	Slab Live Load
Elevation	0	cm	Distance between slab up level and story up level (down direction (-))
Ok			Cancel

There is no need to enter any information in the Slab ID section. The software automatically assigns names while drawing.

H Slab thickness is entered as centimeters.

Slab concrete dead load should not be entered while entering slab coating weight per unit area. The software automatically calculates the dead load of the slab, regarding slab thickness. Weights of coating materials over and under the slab concrete are calculated and values (coating, screed, drop ceiling, ceramic, timber, etc.) are entered in kg/m2.

Slab live load should be selected by the user, as per TS.498 terms.

After entering data in Draw Slab form, the window is closed by clicking OK. Desired number of slabs are drawn by marking first and second points, so that they go through the axis intersections drawn earlier.

In order to keep the program in Drawing mode, Draw Slab toolbar should not be closed while drawing.

3.5- DRAWING HORIZONTAL BOND BEAM

To draw horizontal bond beam, horizontal bond beam properties form is displayed by clicking the

HBB

button in the main window.

Horizontal Bond Beam Properties		
General		
Beam ID	H101	
Beam Width	20	_ cm
Beam Height	50	
Extra G Load	0	kg/m
Extra Q Load	0	kg/m
Eccentricity	0	cm
OK Cancel		

There is no need to enter any information in the Beam ID section. The software automatically assigns names to beams while drawing.

Beam widths are entered as centimeters. Beam width is recommended to be equal to wall width.

Beam height value is entered. Beam height is recommended to be equal to horizontal bond beam over wall for short gaps, and for the long gaps it should satisfy deflection requirements.

The software pays attention to the horizontal bond beams over wall while drawing. It also automatically generates horizontal bond beams over door and window. Horizontal bond beams over door or window are erased, when a door or window is erased. They are moved when a door or window is moved. After drawing door or window, the user should not draw any horizontal bond beams in that area.

Static and concrete calculations are not performed by the software, as horizontal bond beams are generally used in short gaps. Use of beams with long gaps is not recommended; however, if they are used, static and concrete calculations and drawings must be completed independently. The software constructively draws the horizontal bond beam reinforcements in line with the earthquake code.

() VEE

If a wall is defined over the slab, no load transfer is performed between up story walls and down story slabs. Hence, when it is necessary to define wall over the slab, it would be convenient to draw horizontal bond beam under the wall (down story ceiling) If no horizontal bond beam is present, beam height can be equal to slab height.

Bond beams are used in masonry buildings, as they ensure that vertical loads are evenly transferred to walls and the slabs function according to the calculation estimates (lowers slab deflection by creating extra stiffness over the walls).

3.6- DRAWING VERTICAL BOND BEAM

To draw vertical bond beam, vertical bond beam properties form is displayed by clicking the button in the main window.

Draw Vertical Bond Beam				×
Distance	Width	Height	Eccent	ricity
0 cm 📥 📥 📥	20	40	0	

Vertical bond beam drawing can be performed when button is on and vertical bond beam toolbar is active.

Vertical bond beams are drawn by clicking twice on the main window. First click marks the reference point of the beam. Second click defines the drawing direction of the beam.

Distance

The value to be entered in <u>box</u> box is the distance between the two clicked points.

If the leftmost option is selected in **buttons**, vertical bond beam is drawn left-aligned, based on the value in distance box.

Vert	ical Bond Beam Properti	es	×
Sa	yfa 1		
		_	
Ad	DH1	cm	Vertical Bond Beam Name
d	20	cm	Vertical Bond Beam thickness
L	40	cm	Vertical Bond Beam Lenght
DN	M -20	cm	Distance from joint
e	0	cm	Eccentricity
	ОК Са	ancel	

There is no need to enter any information in the Beam ID section. The software automatically assigns names to beams while drawing.

Beam widths are entered as centimeters. Beam width is recommended to be equal to wall width.

Vertical bond beam length is entered.

Distance From Marked Point determines how far the vertical bond beam will be drawn from the clicked point.

It is recommended that you keep the eccentricity value as zero.

To draw vertical bond beam, you must left-click twice on the main window. First clicked point marks the node of the vertical bond beam. If the second clicked point is horizontally in line (or close) with the first one, vertical bond beam is drawn horizontally (x-x axis oriented). If the second clicked point is vertically in line (or close) with the first one, vertical bond beam is drawn vertically (y-y axis oriented).

3.7- DRAWING DOOR

To draw door, Draw Door toolbar is displayed by clicking the button in the main window.

Draw Door X
Distance Width Height Eccentricity 150 cm and cm 200 cm 0 cm
Door drawing can be performed when button is on and Draw Door toolbar is active.
The value to be entered in box is the distance between the two clicked points.
If the ⊨ option is selected in 🛅 ⊨ ┿ 📫 buttons, door is drawn left-aligned, based on the value
in distance box. If the ┿ option is selected, door is drawn center-aligned, based on the value in
distance box. If the 📑 option is selected, door is drawn right-aligned, based on the value in distance
box.
When button is selected, if the second clicked point is to the right of the first one, the software uses the distance between clicked point and the left side of the door as node distance.
When button is selected, if the second clicked point is to the left of the first one, the software
uses the distance between clicked point and the right side of the door as node distance.
When button is selected, if the second clicked point is above the first one, the software uses the distance between clicked point and the bottom side of the door as node distance.
When is selected, if the second clicked point is below the first one, the software uses the
distance between clicked point and the top side of the door as node distance.
It is recommended that is kept active for functionality.
Door width is entered in box and door height is entered in box.

Doors are drawn by clicking twice on the main window. First click marks the reference point of the door. Second click defines the drawing direction of the door. Performing the first click on the axis intersection point and the next one towards the moving distance over the axis would be appropriate for dividing the wall on the axis and the door to be integrated with the wall. If the door is correctly drawn on the wall, the software will automatically divide the wall into two parts and will create horizontal bond beam over the door.



Figure: Correct wall drawing in plan view



Figure: Incorrect wall drawing in plan view



Correct wall drawing in 3D view



Incorrect wall drawing in 3D view

button allows you to modify additional door properties that are not displayed in the toolbar. It is used for extra modifications. Clicking button displays the Door Properties form.

🔗 Doo	r Properties		_ 🗆 X
ID	К1	cm	Door ID
d	80	cm	Door Width
h	200	cm	Door Height
DNM	150	cm	Distance from Node
KBAA	50	kg/m2	Door Unit Area Weight
	Ok		Cancel

In addition to the information entered in the Draw Door toolbar, door unit area weight value can be changed in Door Properties form.

3.8- DRAWING WINDOW

To draw window, Draw Window toolbar is displayed by clicking the button in the main window.

Draw Window X
Distance Width Height Eccentricity $150 \text{ cm} \stackrel{\text{Cm}}{=} \Rightarrow \Rightarrow 130 \text{ cm} 150 \text{ cm} 0 \text{ cm}$
Window drawing can be performed when button is on and Draw Window toolbar is active.
The value to be entered in box is the distance between the two clicked points.
If the ⊨ option is selected in 🔛 ⊨ 📫 🖶 buttons, window is drawn left-aligned, based on the
value in distance box. If the <table-cell-rows> option is selected, door is drawn center-aligned, based on the value in</table-cell-rows>

distance box. If the = option is selected, door is drawn center-aligned, based on the value in distance box.

When button is selected, if the second clicked point is to the right of the first one, the software uses the distance between clicked point and the left side of the window as node distance.

When button is selected, if the second clicked point is to the left of the first one, the software uses the distance between clicked point and the right side of the window as node distance.

When button is selected, if the second clicked point is above the first one, the software uses the distance between clicked point and the bottom side of the window as node distance.

When button is selected, if the second clicked point is below the first one, the software uses the distance between clicked point and the top side of the window as node distance.

It is recommended that is kept active for functionality.

window width is entered in 130 cm box and window height is entered in 150 box.

Windows are drawn by clicking twice on the main window. First click marks the reference point of the window. Second click defines the drawing direction of the window. Performing the first click on the axis intersection point and the next one towards the moving distance over the axis would be appropriate for dividing the wall on the axis and the window to be integrated with the wall. If the window is correctly drawn on the wall, the software will automatically divide the wall into two parts and will create horizontal bond beam over the window.





Figure: Correct window drawing in plan view

Correct window drawing in 3D view







Incorrect window drawing in 3D view

button allows you to modify additional window properties that are not displayed in the toolbar. It is used for extra modifications. Clicking button displays the Window Properties form.

🔔 Windo	ow Properties	s		- 🗆 X
ID	P1		Window ID	
d	130 0	m	Window Width	
h	150 c	zm	Window Height	
PPY	90 c	cm	Parapet Height of Window	
DNM	150 c	m	Distance from Node	
PBAA	25 k	kg/m2	Window Unit Area Weight	
	Ok		Cancel	

In addition to the information entered in the Draw Window toolbar, window unit area weight value and parapet height of window can be changed in Window Properties form. Parapet height of window is equal to the height of wall section between top of slab and bottom of window (height of bottom of window from top of slab).

3.9- DRAWING FOUNDATION

Important: 1- In order to detect foundation under wall, foundations should be defined from the static axis that goes through the midpoint of walls (eccentricity is possible if desired).

2- In order to detect foundation under wall, foundations should be drawn as a single piece covering the walls.

3- Modeling by drawing a single foundation under all walls of an axis is a better method, with regards to performing step 2.

Foundations should be drawn in foundation story. When you perform copy operation from the basement to foundation story, the axes are copied into foundation story. For this operation, select foundation story in the window displayed by clicking Copy Story button when the active story is the basement story. Later, when foundation is the active story, copied basement axes and wall projections will ease the drawing of foundation.

To draw foundation, Foundation form is displayed by clicking the Foundation button in the main window.

		х
ſ		
Foundation ID	T1	
Foundation Width	80	cm
Foundation Height	40	cm
Left delta	40	cm
Right delta	40	cm
Eccentricity	0	cm
Upper Elevation	0	cm
ок	Cancel <u>H</u> elp	

×

There is no need to enter any information in the Foundation ID section. The software automatically assigns names while drawing.

Foundation width and height is entered in centimeters.

Left delta and right delta values define the extension length of the foundation from axis node, in centimeters. This value can be set as half the foundation width of the opposite orientation.

Eccentricity is the distance of the virtual axis of the foundation center axis to the program axis.

Foundation top level value can be equal to wall bottom level value in gradual buildings and buildings with English basements. Foundation top level value does not affect the way static calculations are performed. In other words, the software can perform load transfer even if foundation bottom level value is not changed in gradual buildings or buildings with English basement.

After setting foundation parameters, exit by clicking OK, and in the main window foundation is drawn by clicking first and second points over the nodes.

3.10 - DRAWING RETROFITTING JACKET (SHOTCRETE)

Important: Retrofitting jacket should be modeled from the static axis passing through wall center.

The term retrofitting jacket refers to the reinforcement operation completed with applying steel mesh by shotcrete or repair mortar on wall, and applying reinforced concrete anchoraged to wall.

To draw retrofit jacket, Wall Retrofit Jacket form is displayed by clicking the **button** in the main window.

Wall Retrofit Jacket Properties		х		
Retrofit Steel Bar Selection				
Jacket ID	C101			
Coating wall thickness	20	cm		
Wall and Jacket Eccentricity	0	cm		
Jacket Left/Down Delta Length	10	cm		
Jacket Right/Up Delta Length	10	cm		
Concrete Jacket thickness	5	cm		
Upper Elevation	0	cm		
Bottom Elevation	0	cm		
Right/Up Side Coating				

Jacket ID is automatically generated by the software; so there is no need for a change. Wall thickness is entered in centimeters. Wall and jacket eccentricity value should be left as zero. Jacket Left/Down Delta Length determines the extension length to left or down, starting from the clicked point; and Jacket Right/Up Delta Length determines the extension length to right or up, starting from the clicked point. Concrete jacket thickness value is entered. If the building is not gradual or the top level/bottom level values on walls are zero, top and bottom levels of concrete jacket should also be left as zero.

If left or down side of the wall will be coated, <a>[If left/Down Side Coating radio button is selected; if right or up side of the wall will be coated, <a>[If left/Down Side Coating radio button is selected.

If the walls are completely jacketed, the software can calculate the required steel bar reinforcement in line with earthquake code 2008 7.F.4 formula. If the user desires to use a specific value, one of the steel mesh options can be used.

Wall Retrofit Jacket Properties	×
Retrofit Steel Bar Selection	
-Select Grid Bar	
Program Auto would choose	
Q106/106	
○ Q131/131	
O Q158/158	
O Q188/188	
O Q221/221	
O Q257/257	
Q295/295	
Ok Cancel	

After exiting with OK button, jacket is drawn by clicking first and second points in the axis of the wall to be jacketed.

Chapter 4 File Menu

New: Deletes current project and opens a new project. This command is not necessary in startup. Command is also represented with \square icon in the top toolbar.

Open: Opens a saved project. Projects saved by the software have .syp file extension. With "Open" command, standard file open window is displayed and projects saved in any folder of the computer can be opened. Command is also represented with 🗁 icon in the top toolbar.

Save: Saves current project. Projects saved by the software have .syp file extension. With "Save" command, standard file save window is displayed and projects can be saved in any folder of the computer. Command is also represented with 🖬 icon in the top toolbar.

Save As: Saves a copy of the project with a new filename.

Rescue Last Project: Projects exited without saving can be restored. When the last project is loaded this way, undo and redo options are enabled for all operations performed in previous session. If the last project is loaded as such, it should be saved with "Save As" command.

Exit: Exits by closing the program. You can also use the closing button on top right.

Chapter 5 Edit Menu

Undo: Reverses all operations performed in the last session, step by step. Undo's can be done any number of times. If you wish to undo operations from the previous session, you can load the previous project at startup by "Rescue Last Project" option and perform undo operation. Command is also represented with \Im icon in the top toolbar.

Redo: All operations that are undone can be repeated by Redo button. Command is also represented with C icon in the top toolbar.

Copy Story: Copies the objects on the current story to other selected stories. Before performing copy story operation, sufficient number of stories should be added to the project by Settings/General Story Settings command or by clicking button in the top toolbar.

癸 Kat Kopyala	
Kopyalanacak Katları Seçin 🥅 TEMEL	Kopyalanacak Yapı Elemanı Tipini Seçin
🗌 ΖΕΜΊΝ ΚΑΤ 🔲 1. ΚΑΤ	 Aksları Kopyala Duvarları Kopyala Güçlendirme Mantolarını Kopyala Döşemeleri Kopyala Döşeme Hesap Akslarını Kopyala Pencereleri Kopyala Kapıları Kopyala Kapıları Kopyala Kiriş Hatılları Kopyala
Tamam	İptal

Stories and construction elements to be copied are selected from the window displayed by Copy Story command. If foundation story is selected among stories to be copied, the software copies only the axes of the active story to the foundation story.

Copy Story command is also represented with 😕 icon in the top toolbar.

Erase: To erase desired objects, first the objects are selected, then Erase command is clicked. Command is also represented with icon in the top toolbar. If there are no selected objects in the active story, the button is not active.

Selection Mode: Only one construction object is active in project data entry in Draw menu. Project objects may first need to be selected, in order to modify them. Toggle selection mode to select objects and exit drawing mode.

To enter selection mode, you can either click the selection mode button in the Draw toolbar of the main window, or you can click Selection Mode option in Draw menu. When the object is in drawing mode (wall, slab, vb.) a right click will automatically cancel the active mode and enter selection mode.

To select objects, you can create a selection frame. Clicking on the objects will also select or deselect them.

To create a selection frame, first and second points of the frame is marked by left mouse click. Selected objects are displayed in orange color.

Command is also represented with Modul icon in the top toolbar.

Make All Objects Unselected In the Story: Deselects all objects. Command is also represented with k icon in the top toolbar.

Make All Objects Selected In the Story: Selects all objects on the story with a single button. After this command is performed, changing elements with Change Property command or applying selection filter will be useful. Command is also represented with killing icon in the top toolbar.

Invert Selection In The Story: Makes selected objects deselected; deselected objects selected. Command is also represented with *c* icon in the top toolbar.

Filter Selection: Among all selected objects, keeps desired objects selected. In the form displayed by clicking this command, keep the checkboxes of the elements that you wish to keep selected as checked. Uncheck the elements that you wish to cancel their selection.

🔗 Seçim Filtreleme		
Ana ekranda seçilmiş yapı elemanlarından seçilmesini istemediğiniz yapı elemanlarının işaretini kaldırınız.		
🗸 Aks	V Düşey Hatıl	
🔽 Duvar	🗸 Карі	
🔽 Döşeme	V Pencere	
🔽 Döşeme Hesap Aksı	🔽 Güçlendirme Mantosu	
🔽 Kiriş Hatıl	V Konstrüktif Manto	
Tümünü Seç	Hiçbirini Seçme	
Tamam	İptal	

Command is also represented with \mathbf{k} icon in the top toolbar. If there are no selected objects in the active story, the button is not active.

Find Object: Selects an object on the story when the object name is known. After the command is clicked, object name is entered in the displayed window, paying attention to lowercase/uppercase letters.

🔗 Yapı Elemanı Bu	l.	
Bulunacak Yapı Elem	anının Tam Adını Giriniz	
Bul ve Seç	Seçimi İptal Et	Pencereyi Kapat

Construction element is selected by "Bul ve Seç" (Find and select) button. This command is particularly useful in selecting incorrect objects that were drawn successively and the bottom objects cannot be selected or located. After Bul ve Seç (find and select) button is used, selected object can be modified by clicking Erase button in edit menu or change properties button.

Command is also represented with \overline{P} icon in the top toolbar.

Chapter 6 View Menu

Select None: Deselects the selected objects in the active story.

Select All: Selects all objects in the active story.

Invert Selection: Makes selected objects deselected; deselected objects selected in the active story.

Erase: Erases selected objects in the active story.

Change property: Changes the properties of selected objects.

When clicked on change property button in the main window, one will be asked for the types of elements that will be changed.

🔔 Öz	özellikleri Değiştirilecek Elemanlar			- 🗆 X
	Duvar		Карı	
	Döşeme		Pencere	
	Döşeme Hesap Aksı		Kiriş Hatıl	
	Temel		Düşey Hatıl	
	Güçlendirme Manto		Konst. Güçl. Manto	
	Yatay Aks Kaydır		Dikey Aks Kaydır	
	Eğik Aks Kaydır			
	Tamam		İptal	

Change Property form is displayed, according to the selected element. Only the sections of the desired property changes should be filled in this form. If the selected objects share any property, relevant box will display a value (e.g. unit weight, beam height, fem, to, material). If selected

object have different properties, relevant boxes will display zero or will be blank (e.g. wall ID, wall width). Only the values related to the filled boxes will be changed in selected objects.

Duvar	Özellikleri			x
Anali	iz Seçenekleri	Statik/Malzeme	Analysis Options	
	Ivar Malzeme S (*A/H ifadesing (*A/H ifadesing E3 Düşey delikl E4 Dolu blok tu E5 Taş duvar (r E6 Gazbeton (t E7 Dolu beton l E8 Özel Tanımlı	ieçimi deki k rijitlik çarpaı deki k rijitlik çarpaı i blok tuğla (delik o ğla veya harman çimento takviyeli k utkal ile) briket (çimento ha	nını program otomatik seçsin) nı için özel değer kullan oranı %45'den fazla, çimento takviyeli kireç harcı ile) tuğlası (çimento takviyeli kireç harcı ile) kireç harcı ile) arcı ile)	
Seçile	Seçilen Duvar Malzemesinin			
Birim	Hacim Ağırlığı	0	kg/m3	
fem		0	Mpa Duvar Basınç Emniyet Gerilmesi (Narinlik Azaltması Yapılmamış)	
το		0	Mpa Duvar Çatlama Emniyet Gerilmesi	
Güçlendirme Projelerinde fem ve to kutucuklarına duvarların mevcut malzeme dayanımları girilecektir.				
			OK Cancel Help	

If Change Property option from the menu displayed by right-clicking on a selected object is clicked, Change Property window of the hovered element will be displayed.

In addition, right clicking on any object in the drawing area allows changing property of the hovered object.

LOAD TRANSFERS

LOADS TRANSFERRED BY HORIZONTAL BOND BEAM

Description:

Horizontal bond beam: Horizontal beams over door or window gaps and in user-defined building parts, with no filled walls or no walls underneath are referred to as horizontal bond beam.

Horizontal bond beam over wall: Construction elements that evenly distribute the loads to walls, where their width is same as the wall and their height is set from Draw Wall form.

The software automatically pays attention to the horizontal bond beams over wall while drawing. Beams should not be drawn once more over drawn walls.

The software also automatically generates horizontal bond beams over door and window. Horizontal bond beams over door or window are erased, when a door or window is erased. They are moved when a door or window is moved. After drawing door or window, the user should not draw any horizontal bond beams in that area.

Horizontal bond beams may be used for purposes like shrinking slab gaps, increasing the stiffness of cantilever slabs, etc.

If the user-drawn horizontal bond beams are desired to transfer loads to walls, one of the left or right ends of the beam should start from the wall axis.

Static and concrete calculations are not performed by the software, as horizontal bond beams are generally used in short gaps. Use of beams with long gaps is not recommended; however, if they are used, static and concrete calculations and drawings must be completed independently. The software constructively draws the horizontal bond beam reinforcements in line with the earthquake code.

Bond beams are used in masonry buildings, as they ensure that vertical loads are evenly transferred to walls and the slabs function according to the calculation estimates (lowers slab deflection by creating extra stiffness over the walls). The software transfers the distributed loads in the slabs to horizontal bond beams and walls around, by automatically calculating dead weight. Horizontal bond beams receive load from the following elements:

1- Self: Dead weight of element

2- Weights of Up Story walls; and dead and live loads on this walls

3- Slab dead and live loads connected to the axis in the story of the horizontal bond beam

4- Vertical bond beam loads on horizontal bond beam up story and that does not continue on the story of horizontal bond beam (including external loads on vertical bond beam, both dead and live)

5- Dead weight of the wall section over door or window below the horizontal bond beam

6- Dead weight of the door or window and dead weight of the parapet under the window on horizontal beam up story

7- Dead and live loads of another horizontal bond beam anchoraged to the beam

Horizontal bond beams transfer load to the following elements:

1- Story walls, to which left or right end of the beam is connected (if there are multiple walls at the left or right end of the beam, the loads to be transferred by the horizontal bond beam is automatically divided to the number of walls)

a - If one end of the horizontal bond beam is at loose, the software automatically considers it as a cantilever and transfers all loads to the construction element it is connected to.

b - If both ends of the horizontal bond beam are at loose, a warning message is displayed during analysis.

c - Horizontal bond beam separates received loads as G and Q and transfers loads evenly to both ends.

Wall and Vertical Bond Beam transfers to be added to the Help file.

LOAD TRANSFERS BETWEEN STORIES

As is known, earthquake code dictates that the walls should overlap. If load transfer is desired in down story and up story walls, it is enough for the walls to overlap roughly. Walls do not need to be drawn from the same axis for load transfer. Load transfer of the walls between stories is performed under the situations listed below.



As seen in the figures, load transfer is performed in the case that at least one edge of the up story wall projection lies within down story walls. Load transfer of walls can be controlled from wall load reports.

Performance Evaluation and Strengthening of Masonry Constructions via StatiCAD-Yigma

Introduction

StatiCAD-Yigma software performs structural (static) calculations for masonry constructions as per earthquake regulations based on the principles of the theory of elasticity.

Scope

Principles of calculations for masonry construction are mainly within the scope of the theory of elasticity. (Allowable/Working stress method) Static and performance analyses of an existing construction, static and performance analyses of strengthened buildings and composite section investigations of strengthened buildings can be performed with StatiCAD-Yigma software.

In order to perform mentioned calculations, the checkbox "Project General Settings>Performance>This project is the current structure checkup and/or Retrofit project" must first be checked. After then, appropriate selections must be made in the Project General Settings form.

DETERMINING THE EARTHQUAKE PERFORMANCE OF AN EXISTING BUILDING

1- Construction modeling is carried out based on the construction drawing and building survey and measurements on the construction site.

2- fd value (wall's pressure strength) must be filled in the fem (pressure safety stress of wall) textbox in the Wall Properties form. Pressure strength values can be obtained empirically, or by following table values in line with Earthquake Code 2007, article 5.3.2.

3- Wall Properties values are defined or modified according to values obtained empirically or by measurements in the building.

4 - In order to perform earthquake performance of the existing construction the checkbox "Project General Settings>Performance>This project is the checkup and strengthening project of the current construction" must be checked.



5- When Project General Settings>Performance>"This project is the checkup and strengthening project of the current construction" checkbox is checked, if Project General Settings>Retrofit>"Use retrofit jackets stiffness and weight in the analysis" checkbox is not checked, retrofitting jackets will not be considered in the performance report of the existing building and the report title will be "MEVCUT BINA DEPREM PERFORMANS RAPORU (GÜÇLENDIRME ÖNCESI)" (EXISTING BUILDING EARTHQUAKE PERFORMANCE REPORT (BEFORE RETROFITTING)).

6- When Project General Settings>Performance>"This project is the checkup and strengthening project of the current construction" and Project General Settings>Retrofit>"Use retrofit jackets stiffness and weight in the analysis" checkboxes are checked, retrofitting jackets' weights and stiffness will be considered in the performance report of the building and the report title will be "GÜÇLENDİRİLMİŞ BİNA DEPREM PERFORMANS RAPORU" (RETROFITTED BUILDING EARTHQUAKE PERFORMANCE REPORT).

7- When you select building level from Project General Settings>Performance>Building Information Level as per the terms of earthquake code article 7.2.13, element capacities (pressure safety stress and shear resistance stress) are multiplied by information level coefficients as a result of the analysis.

8- Project General Settings>Performance>Spectrum Acceleration Factor value selected as per the terms of earthquake code Table 7.7 is multiplied by earthquake forces. Building importance factor is not used in existing building examinations and retrofittings (I=1 for every building type).

Drawing Retrofit Jackets

1- In order to calculate composite capacities of walls (with jackets), retrofit jackets and walls should be defined in the same axis.

Wall Retrofit Jacket Properties		X
Retrofit Steel Bar Selection		
Jacket ID	C101]
Coating wall thickness	20	cm
Wall and Jacket Eccentricity	0	cm
Jacket Left/Down Delta Length	10	cm
Jacket Right/Up Delta Length	10	cm
Concrete Jacket thickness	5	cm
Upper Elevation	0	cm
Bottom Elevation	0	cm
Lett/Down Side Coating		
Right/Up Side Coating		
Ok Cancel		
Ok Cancel		

2- There is no need to change Jacket ID section

in Wall Retrofit Jacket Properties. The software auto-names the elements; if the elements are drawn in mixed order, automatic sorting can be performed by clicking Order button in the top toolbar.

3- Wall thickness value is entered in Coating Wall Thickness box.

4- Jacket left/down delta length value of outer wall jackets can be set as half the width of the wall anchoraged from left or down of the wall to be jacketed. Left/down delta length determines the back/forth imminence of the left/down axis where the jacket is defined. Positive or negative values can be set.

6- Jacket left/down delta length value of inner wall jackets can be set as half the width of the wall anchoraged from left or down of the wall to be jacketed, as negative (e.g. -10). Left/down delta length determines the back/forth imminence of the left/down axis where the jacket is defined. Positive or negative values can be set.

7- You can refer to entries (5) and (6) for Right/Up delta length definitions.

8- Concrete jacket thickness should be at least 3 cm, as per the Earthquake Code. Jacket thickness is a factor in determining the earthquake load of the jackets, when static calculation is performed with respect to stiffness of the jackets.

9- Bottom Level: If you are modeling basement story and your building is gradual, you can equal the jacket bottom level to wall bottom level.

10- Top Level: If you are modeling top story and your building is gradual, you can equal the jacket top level to wall top level. If jacket top or bottom level values are entered as different from wall top or bottom level, analysis may produce unexpected results.

11- If jacket top or bottom level values are different from wall top or bottom level, the earthquake performance of the building may be poor.

12- You can activate Left/Down side coating option, in order to coat left face of vertical walls or down face of horizontal walls.

13- You can activate Right/Up side coating option, in order to coat right face of vertical walls or upper face of horizontal walls.

14- After clicking OK, mark the first and second endpoints of the jacket by clicking axis intersection points in the main modeling window. Jacket will be drawn.

15- If you wish to consider the contribution of retrofit jackets on pressure safety stress, or calculate them by the help of earthquake code's formula 7F.4, you should set the starting and ending points of outer wall jackets as equal to or greater than wall starting and ending points (by definition of 7F.4 formula).

15- If you wish to consider the contribution of retrofit jackets on pressure safety stress, or calculate them by the help of earthquake code's formula 7F.4, you should set the starting and ending points of inner wall jackets as equal to or greater than wall starting and ending points (by definition of 7F.4 formula).

As the jacket will be drawn in jacket and wall cross-section (jacket and the perpendicularly anchoraged wall intersection area), there will be an excess in jacket stiffness, as much the length of wall cross-section. However, this situation is considered in the analysis and no difference is produced in calculations, as jacket area is shrunk as the size of intersection area. In addition, trimming the jacket line in drawings in jacket/wall intersection will be convenient.

16- Wall jacket is drawn to cover door or window opening, jackets are automatically divided by door or window openings and constructive jackets are automatically produced.

Detailed information regarding constructive jackets is provided in the next chapter.

What is a constructive jacket?

Door or Window Up and Down Wa	II Jacketin	g	x
Constructive Retrofit Jacket			
Jacket ID	FCB1	cm	
Wall and Mantle eccentricity	-12.5	cm	
Jacket Concrete Thickness	5	cm	
Up Flevation	0	cm	
Down Elevation	0	cm	
Door or Window Height	200	cm	
If window lower parapet height	0	cm	
Information Note: Constructive Retrofit Jacket is the continue of jacket on window paraphet wall, wall part above the door or window.Constructive Retrofit Jacket increases the rigidity of Jacket (the jacket between doors and windows) and retrofitting effect. When Jacket is drawed Constructive Retrofit Jacket is Autogenerated on door or window by the application. Properties of Constructive Retrofit Jacket can be changed by this form.			:
	ОК	Cancel	

Note: Constructive retrofitting jacket is the extension of the jacket in wall sections under/over the window or over the wall. Extending the jacket in wall openings increases the stiffness of the jackets in filled walls and therefore provides a better retrofitting. While drawing retrofit jackets, constructive coats corresponding to doors or windows are automatically produced by the software and their properties can be changed by changing the information in this form.

In order to perform a Performance Evaluation of a Masonry Construction with StatiCAD-Yigma software, relevant options should be selected in General Project Settings window; in Performance, Retrofit and Other Options tabs.

Retrofit options and their effects on analysis reports are listed as follows.

RETROFITTED BUILDING ANALYSIS OPTIONS

Earthquake (TDY) Material Load Combinations Performance Retrofit Other Options
Use Retrofit Jackets Stiffness and weight in the analysis Ejc/Ewall O Jackets Elasticity Module Wall Elasticity Module Ratio
Calculate Retrofit Jackets additive to Wall Pressure Admissible Stress
For Retrofit Jacket Shear Capacity Calculation Use
Vjacket=Jacket Horizontal Section Area *Shear Strength of Concrete Layer Formula Shear Strength of Concrete Layer 1 Mpa
Calculate Retrofit Jackets additive to Wall Shear Capacity by 2007 Earthquake Code
$Vwall = Awall (twall + fydpsh) \le 0.22$ Awall fwall (7F.4) Formula
?Open Retrofit Help File
OK Cancel <u>H</u> elp

In order to consider retrofit jackets in the project, "Use retrofit jackets stiffness and weight in the analysis" checkbox should be checked. When this box is checked, retrofit jacket weights are added to dead weights of walls. Unit weight of the retrofit jacket is entered as 2500 kg/m³.

Stiffness of retrofit jackets are considered with the ratio entered in Ejc/Ewall (Jacket's elasticity module/Wall elasticity module ratio) box.

For example, if Ejc/Ewall ratio = 5 in a jacket with 5cm thickness and 300cm length, stiffness of the jacket is calculated by adding Ejc/Ewall factor to k*A/H formula and is therefore (Ejc/Ewall)*k*A/H=(5)*1*(0,05*3)/H. H in this formula is the height of the shorter gap among door or window openings. If there is no door or window opening at jacket ends, H value is entered as equal to height of story.

For H value to be considered as the shorter one of the door or window openings at jacket ends, there should be a constructive jacket defined over and below the window or over the door.

As is seen in the formula, considering H value of the doors and windows at jacket ends will increase jacket stiffness and therefore increases the earthquake force of the jacket.

Entering Ejc/Ewall ratio is one of the most important steps in retrofit project, and it determines the earthquake load of the jackets.

If this value is entered as zero, no earthquake load will act on jackets. This will also increase the shear capacity of the wall it is connected, by reason of the minimum reinforcement to be placed in the jacket.

If you do not wish to determine jacket stiffness with Ejc/Ewall ratio calculated regarding the theory of elasticity, you can define a specific stiffness factor for the retrofitted wall. Of course, the stiffness factor you define should be based on generally accepted approaches and calculations.

As is known, wall stiffness was defined as k^A/H and k in the formula could be equal to 1 or 1,2 with respect to the wall's endpoints.

Increasing k value for retrofitted wall would increase the shear force of the wall by the given ratio.

In Wall Properties dialog box, you can perform analysis with custom defined k factor, by defining how much the retrofitting increases the current wall stiffness.